


# Scale-Link™

## Version 3.0

The industry standard take-off tool for entering linear measurements from your blueprints, maps, or plans into any Windows program. Just roll the scaler wheel along your print, then click to instantly transfer the measurement into your program. Scale-Link includes the scaler wheel, connecting cable and transfer software.




Select units of readout  
(inches, feet, yards, meters, etc.)

Change serial port, user  
defined scales, etc.

Zero the count  
and length

Click here to  
transfer length from  
PlanWheel PC into  
software program

Transfer count from  
PlanWheel PC into  
software program



Select scale factors  
(architectural,  
engineering,  
map, metric)

The Ready Connect™ window indicates readout  
from the PlanWheel PC™.

### Scale-Link Includes:

- PlanWheel PC™ Scaler
- Ready Connect™ Software
- Protective Case
- One Year Warranty
- User Manual

### Scale-Link is specially suited for:

- All Windows construction estimating software
- Excel®, Quatro Pro®, Lotus 1-2-3® and other spreadsheets
- Access®, dBase®, Paradox®, Foxpro®, and other databases

### System Requirements

- Windows® Compatible Computer
- 3-1/2" Floppy Disk Drive or
- CD-ROM Drive
- Serial Port (9 or 25-pin)

Scale-Link works with all Windows® operating systems.

Also available: PlanWheel (non-computerized scaler), USB converter adapter